

## Library – Files missing

### Symptoms:

The audio library contains more than 4,000 audio files, and seems to be missing files from the library. This may also affect files from playing and the Xtreme may not recognize some files and report them as missing.

### Solutions:

The default size of the Digilink-Xtreme Library is 4,000 files. When the user exceeds 4,000 total files in the Library it is then required to create a text file to allow the Xtreme to use more audio files. To do this:

- 1) go to the **C:** drive
- 2) open the **Arrakis** folder
- 3) open the **Xtreme** folder
- 4) open the **DigilinkSetup** folder
- 5) inside this folder, right click and select **New, Text Document**. This will create a text document in the **DigilinkSetup** folder
- 6) rename the text document from **New Text Document** to **librarysize**
- 7) open this text document
- 8) type **6000** into the text document
- 9) click on **File** and select **Save**
- 10) Restart the **Digilink-Xtreme** software

To verify that it worked:

- 1) click on **MENU** in the Xtreme
- 2) click on **SETUP**
- 3) in the middle of the **SETUP** screen it will show **Library size =** and then the new value. If it is still at 4000 files, then follow steps 1 – 10 again